#290500 The Weems & Plath® Admiral Quartz Clock



Weems & Plath®

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA 410-263-6700 • fax 410-268-8713 • www.weems-plath.com E-mail: support@weems-plath.com

Operating Instructions

- Remove the three (3) screws and brass plate on the back of the case to expose the back of movement and battery compartment.
- 2) Insert an alkaline battery, following the diagram on the battery housing to make certain the battery is not put in backwards. Use only alkaline batteries as they have longer life and are less prone to leakage.*
- To set the time, advance the hour and minute hands by turning the knob on the back of the movement in the counterclockwise direction. To reverse, turn clockwise.
- 4) If clock stops, it is most likely due to a dead battery. Remove the battery immediately as it will leak acid causing damage to the movement which will void warranty.*
- 5) If clock is to be left unattended for long periods of time, the battery should be removed, otherwise it could become dead and leak acid causing damage to the movement which will void warranty.*