

QUARTZ SHIP'S BELL CLOCK

Operating Instructions

- 1) Open case lid (bezel) to expose back of movement. If case has screw-on type bezel, simply unscrew bezel. If case has hinge type of bezel, unscrew latch and flip bezel open. If you have an Orion model, see "Drop in Module" addendum.
- 2) Open battery cover and insert a size AA alkaline battery. Follow diagram on battery to make certain battery is not put in backwards. Use only alkaline batteries as they have longer life and are less prone to leakage.*
- 3) To set the time, advance hour and minute hands by turning the knob on the back of the movement counter-clockwise. If passing through either the half or full hour, turn the bells off or wait at each bell sequence until all bells are finished.

Special Note: When the bell switch is turned back on or the battery is replaced, the bell may ring and will probably be out of the correct sequence. After the clock has run for about an hour, it should correct itself.

- 4) To silence bell, slide switch marked bell. When viewing the movement from behind, slide to the right to activate chimes. The chiming sequence is regulated automatically within the movement.
- 5) If clock stops, it is most likely due to a dead battery. Remove the battery immediately as it will leak acid causing damage to the movement which will void warranty.*
- 6) If clock is to be left unattended for long periods of time, the battery should be removed, otherwise it could become dead and leak acid causing damage to the movement which will void warranty.*

Weems & Plath®

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA
410-263-6700 • fax 410-268-8713 • www.weems-plath.com

E-mail: support@weems-plath.com

01/03