



CrewWatcher®

Patent Pending

MOB alarm
the fastest way to rescue

Getting Started Guide

Weems & Plath®

Getting Started

1 Download the app

The Weems & Plath CrewWatcher system consists of two parts; beacon(s) and a mobile software application or “app.”

The app works on both Apple iOS and Android devices. Download the app from the App Store on Apple devices or the Google Play Store on Android devices. Search for: CrewWatcher.

Alternatively, scan this QR code to open the app store download page directly. The app name is CrewWatcher.



Tip

If you get stuck or have any questions please visit:
www.crewwatcher.com/help


Getting Started

2 Activate your beacon(s)

3 Modes of Beacon Activity:

- **Hibernation** - long term beacon storage
- **Sleeping** - beacons standing by (app disabled)
- **Watching** - beacons enabled (app activated)

New beacons are placed in hibernation mode at the factory to save battery life. Activate your new beacon by submerging it in water. Keep the beacon underwater for at least 30 seconds, then take it out and dry it off. When activating, make sure that the water sensors at the bottom of the beacon are completely submerged or it will not activate.



Tip


Put your beacon(s) in a large container of water such as a bowl or bucket (not a drinking glass) so the beacon can float on its side rather than upright.

Getting Started

3 Pair your beacon(s)

It's time to link your beacon(s) with your Apple or Android device.

1. Hold one beacon against an edge of your device with the beacon logo facing it while keeping the other beacon(s) at least six feet away.



2. Open the app and press the “Add a Beacon” button. The app searches for beacons that are in range.

Add a Beacon +

Getting Started


3. As a beacon is pairing, you should see the white bar turn blue.



4. Once complete, you can add a picture and name to the beacon icon on the device. This will help with identification in the future. Tap the camera icon to select or take a picture.



5. If you have more beacons to pair, press the blue "Setup more" button and repeat step 3 of this guide. Otherwise, press "All Done" to return to the dashboard.



Getting Started

4 Using CrewWatcher

Congratulations! Now that you've paired beacon(s) to watch, you can activate CrewWatcher on your device. It's really easy - tap the top right toggle and wait for all beacons to display "watching." The background will turn from gray to green.



IMPORTANT: When you are finished, always disable CrewWatcher by tapping the same, top right toggle. All beacons and the toggle should now turn gray to mark the beacons' sleeping mode. This will preserve battery life and eliminate unintended alarms.



To register your product visit:
www.weems-plath.com/product-registration

Tips and Tricks

Beacon wearing position

We recommend you wear the beacon attached high on your life jacket. Secure it to one of the jacket's straps to prevent loss of the beacon.



Range settings, boat size and deck material

CrewWatcher works best on boats that have a non-metal deck. If you are experiencing problems with false alarms, we recommend changing the beacon's power and range settings in the app's side menu under "Settings."

Note: Increasing the power and range setting will consume additional battery power in the beacon.

Tips and Tricks

Phone or tablet position on the vessel

We recommend keeping a dedicated phone or tablet in a central location on the vessel where it can be provided with power and plugged into the on-board stereo or connected via Bluetooth to a speaker.

IMPORTANT: Do not keep the monitoring phone or tablet on your person. If you go overboard with the phone or tablet, there is no way to alert your crew.

Connection issues

CrewWatcher beacons require Bluetooth 4.0 or higher. If your device does not support Bluetooth 4.0 the app will not be able to pair your beacon(s).

If encountering connection errors in the app; first try to re-pair the beacon. If you experience repeated connection errors, disable the watch and wait for at least 13 hours. The beacon will automatically reset itself every 12 hours if left idle.



Legal

TERMS & CONDITIONS

By using this product you agree to all of the terms of service that can be found at our websites: www.crewwatcher.com and weems-plath.com and contained within the packaging of this product. You further agree that you will use CrewWatcher only as intended and will follow all instructions concerning its proper use and will adhere to all warnings associated with the product. CrewWatcher should be considered an aid to safe boating. It should not be considered a safety or rescue product. Sailing or boating is an inherently dangerous endeavor and it is imperative that you follow all federal and state boating regulations when operating a vessel. In the event that an occupant of a vessel properly using CrewWatcher goes overboard there is no guarantee that the occupant will be successfully rescued.

DISCLAIMER OF IMPLIED WARRANTIES

SELLER DISCLAIMS ALL IMPLIED WARRANTIES AND SIMILAR OBLIGATIONS INCLUDING BUT NOT LIMITED TO THOSE OF FITNESS FOR A PARTICULAR PURPOSE, AND MERCHANTABILITY, WHETHER OTHERWISE ARISING BY LAW, CUSTOM, USAGE, TRADE PRACTICE, COURSE OF DEALING, OR COURSE OF PERFORMANCE. There are no warranties which extend other than those express warranties contained on our website or within the packaging of this product. Weems & Plath does not warrant CrewWatcher will comply with the requirements of any safety code, rule or regulation of any federal, state, local government or other jurisdiction other than those express warranties in the Agreement.

Weems & Plath will not be liable to any person using CrewWatcher in the event of injury or death for compensatory, punitive, incidental, consequential or other damages and Weems & Plath assumes or undertakes NO LIABILITY for any loss or damage suffered as a result of the use, misuse or reliance on CrewWatcher.

Weems & Plath®

To activate the two-year warranty,
please register your product at
www.weems-plath.com/product-registration

214 Eastern Avenue, Annapolis, MD 21403 USA
www.weems-plath.com • 410-263-6700

Contains FCC ID: QOQBGM111