

LIMITED LIFETIME NEW PRODUCT WARRANTY

Your Weems & Plath® quartz clock (not including quartz bell movements) quartz time & tide clock, barometer, thermometer, or barometer/thermometer movement is warranted against defects in material and workmanship for as long as you own the instrument. In the event of any such defect, return the instrument postage prepaid along with *proof of purchase* and an explanation of the defect to the address below and it will be repaired or replaced at our option and at our expense. Any defect caused by misuse, accident, tampering, or negligence of the user is not covered by this warranty. The repaired or replaced instrument will be returned to you postage prepaid.

NOTE: If your instrument is battery operated, movement damage caused by battery leakage is not covered under this warranty.

All implied warranties covering merchantability, fitness for particular purpose, or otherwise are limited in duration to as long as you own the instrument. The repair or replacement of any defect is the exclusive remedy under this warranty. In addition, the warrantor shall not, under any circumstance, be liable or responsible hereunder for consequential, incidental, indirect, or special damages.

Note that some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have rights which vary from state to state.

NOTE: This warranty applies to all quartz clock movements, quartz time & tide clock movements, barometer movements, thermometer movements and barometer/thermometer movements other than the Weems & Plath® Trident® line. Furthermore, it specifically excludes all quartz bell movements. Our standard two (2) year warranty applies to all instruments not covered by our lifetime warranty.



214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA
410-263-6700 • fax 410-268-8713 • www.weems-plath.com
E-mail: support@weems-plath.com 09/03

CARE OF THE CASE

Your brass case is finished with the highest quality lacquer to prevent tarnishing.

Care must be taken to protect the lacquer coating. All finger prints should be wiped off immediately. The case should be cleaned regularly with a soft cloth. We have found that a combination of dust and other airborne pollution when mixed with moisture created by humidity, will destroy the finish.

Never use a brass cleaner on the case as this will immediately damage the lacquer coating.

If any water, particularly sea water, comes in contact with the lacquer finish, remove it immediately.

MOUNTING ON A BOAT

The lacquer coating on this unit will eventually deteriorate, but with proper care the coating will last for many years with no noticeable deterioration.

We recommend the use of a "Solar Fan Vent" in your boat. It will not only prolong the life of your clock, but also cushions, woodwork and everything else on board.

The greatest amount of care must be taken in a warm, moist, very salty environment as this will deteriorate the lacquer very quickly.

We strongly recommend that the instruments be removed from your boat during the winter months if the boat is not being used.

* Sun activated deck fan which exhausts the stagnant cabin air.

NOTE: Please keep your original receipt, your warranty can not be honored without it. Package carefully as Weems & Plath® can not be responsible for damage in transit. Include a note describing the problem, your phone number, mailing address, and proof of purchase if claiming warranty.