

# ANNIVERSARY 8-DAY WIND SHIP'S BELL CLOCK

## Operating Instructions

To operate clock please observe the following steps:

- (1) Remove plastic tube inserted in wind hole located on the face of the clock. Tube is inserted to keep minute hand from rotating in transit.
- (2) Clock will only strike when in vertical position.
- (3) Bell switch is located on left hand position of face between 10 and 11 o'clock. "Fast/slow" switch is located on right hand side of face between 12 and 1 o'clock. Simply slide switches to the left or right for desired bell and time adjustments. Clock will run if bells are turned on or off.
- (4) To set time, rotate the minute hand clockwise only to the desired time. Care should be taken to not touch hour hand.
- (5) Wind the bell spring and main spring clockwise only. Do not exert force, as over-winding will damage the mechanism.\* Clock should be wound every 7 days, preferably at the same time of day.

**Weems & Plath®**

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA  
410-263-6700 • fax 410-268-8713 • [www.weems-plath.com](http://www.weems-plath.com)  
E-mail: [support@weems-plath.com](mailto:support@weems-plath.com) 3/12

## **ANNIVERSARY 8-DAY WIND SHIP'S BELL CLOCK TROUBLE SHOOTING**

Clock runs fast  
or slow

- A. Adjust slow (-) fast (+) mechanism.  
Allow a 24 hour period to pass before  
readjusting to "zero-in" on proper running  
rate.
- B. Return for service.\*\*

Clock will not  
run

- A. Remove tube to free minute hand.
- B. Wind clock.\*
- C. Rock gently side to side
- D. Return for service.\*\*

Clock will not

- A. Wind bell spring.
- B. Slide bell switch on.
- C. Return for service.\*\*

\* **Overwinding will void warranty.**

\*\* **When returning for service, be sure to package very carefully as Weems & Plath® can not be responsible for damage in transit. Be sure to include a note describing the problem, your phone number, mailing address and proof of purchase if claiming warranty. Have the minute hand held by the plastic tube in the same manner it arrived.**

**Weems & Plath®**

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA  
410-263-6700 • fax 410-268-8713 • [www.weems-plath.com](http://www.weems-plath.com)  
E-mail: [support@weems-plath.com](mailto:support@weems-plath.com) 3/12